



Key Fob Pairing Button

RP-SMA Key Fob Receiver Antenna Connector

Raspberry Pi2 Pass-Through Connector

Key Fob Pairing Button

LINX Lical Key Fob Decoder: (MS Series Key Fob)
 Key Fob Button 0 is Connected to Raspberry Pi2 Pin 29 - GPIO5
 Key Fob Button 1 is Connected to Raspberry Pi2 Pin 31 - GPIO6
 Key Fob Button 2 is Connected to Raspberry Pi2 Pin 33 - GPIO13
 Key Fob Button 3 is Connected to Raspberry Pi2 Pin 35 - GPIO19
 Key Fob Button 4 is Connected to Raspberry Pi2 Pin 37 - GPIO26
 Key Fob Button 5 is Connected to Raspberry Pi2 Pin 40 - GPIO21
 Key Fob Button 6 is Connected to Raspberry Pi2 Pin 38 - DPIO20
 Key Fob Button 7 is Connected to Raspberry Pi2 Pin 36 - GPIO16